


PRO-2067 500-Channel Mobile Trunk-Tracking Scanner

Please read before using this equipment.



RadioShack®

INTRODUCTION

Your new RadioShack 500-Channel Mobile Trunk-Tracking Scanner is one of a new generation of scanners designed to track Motorola™ Type I, Type II (such as Smartnet™ and Privacy Plus™), GE/Ericsson EDACS, E.F. Johnson LTR™, and hybrid analog trunking systems, which are extensively used in many 800 MHz, 900 MHz and UHF communication systems.

Trunking communications systems let a large group of 2-way radio users (or even different groups of 2-way radio users) efficiently use a group of frequencies. Instead of selecting a specific frequency for a transmission, the 2-way radio user simply selects a talk group. The trunking system automatically transmits the call on the first available frequency, and also sends a code that uniquely identifies that 2-way radio user's transmission on a different frequency called a data channel.

Since the trunking system might send individual 2-way radio user's calls and response transmissions on different frequencies, it is difficult to listen to trunked communications using a regular scanner. The scanner monitors the data channel frequency sent with a 2-way radio user's transmission and instantly switches to an active frequency, so you can hear the call and response for that 2-way radio user and easily "follow" the conversation.

The scanner also lets you scan conventional transmissions, and is pre-programmed with service-search banks for convenience. By pressing a single button, you can quickly search those frequencies most commonly used by public service and other agencies without tedious and complicated programming.

This scanner gives you direct access to over 33,000 frequencies, including those used by police and fire departments, ambulance services, and amateur radio services, and you can change your selection at any time.

FEATURES

Your scanner also has these special features:

Ten Channel-Storage Banks — let you store 50 channels in each bank (500 total channels), letting you group channels so you can more easily identify calls.

Flexible Operation — you can track Motorola, GE/Ericsson, and E.F. Johnson LTR trunking systems (used by most trunking communications systems), letting you hear more calls than many standard trunking scanners.

© 2000 RadioShack Corporation.
All Rights Reserved.

RadioShack, RadioShack.com, HyperSearch, and HyperScan are trademarks used by RadioShack Corporation.

Simultaneous Trunking Operation

— you can scan all 3 types of trunking systems, and both trunking and conventional frequencies, at the same time.

Text Input — you can manually enter the name of the service you are listening to so the service name appears when you scan it, making it easier to identify transmissions.

Digital Weather Alert — displays the weather event text so you can see the reason for the alert.

Note: The scanner does not display the actual location referenced by SAME messages. It uses only the message portion of the SAME signal.

Ten Preprogrammed Frequency Ranges — let you search for transmissions within preset frequency ranges or within ranges you set, to reduce search time and select interesting frequencies more quickly.

Private/Digital Private Line Receiving — decodes and displays the Continuous Tone Coded Squelch System (CTCSS) and Digital Coded Squelch (DCS) tone signal being transmitted, letting you see if the transmitter provides these services.

12-Character, 4-Line, Dot-Matrix Display — makes it easy to view and change displayed information.

Frequency Coverage to 960 MHz — provides a wide range of frequencies you can listen to.

Clone/Remote PC Function — lets you transfer programmed data directly to another Cat. No. 20-196 or Cat. No. 20-522 scanner. You can also upload or download the programmed data to or from a PC using an optional interface kit.

Triple-Conversion Circuitry — virtually eliminates any interference from IF (intermediate frequency) images, so you hear only the selected frequency.

Scan Delay — delays scanning for about 2 seconds before moving to another channel, so you can hear more replies that are made on the same channel.

Lock-Out Function — lets you set your scanner to skip over specified channels or frequencies when scanning or searching, and skip over IDs when tracking trunked systems.

Priority Channel — lets you program one channel as the priority channel. As the scanner scans it checks the priority channel every 2 seconds so you don't miss transmissions on that channel.

ATT (Attenuate) Button — lets you program each memory location to reduce the scanner's sensitivity to strong local signals, to reduce interference or noise caused by these signals.

HyperSearch™ and HyperScan™ — let you set the scanner to search at up to 50 steps per second and scan at up to 25 channels per second, to help you quickly find interesting transmissions.

DIN-E Size Cabinet

Supplied Frequency Guide — lists the frequencies for many of the public safety systems you can listen to.

Memory Backup — keeps the channel frequencies stored in memory for an extended time even without battery power.

Your scanner can receive these bands:

Frequency Range (MHz)	Types of Transmissions
29–54	10-Meter Ham, VHF Lo, 6-Meter Ham
108–136.9875	Aircraft
137–174	Military Land Mobile, 2-Meter Ham, VHF Hi
380–512	Federal Government, 70-cm Ham Band, UHF Standard Band, UHF “T” Band
806–823.9875 849–868.9875 894–960	Public Service “800” except Cellular Band

This Owner’s Manual also includes the section “A General Guide to Scanning” on Page 44 to help you target frequency ranges in your service area so you can search for a wide variety of transmissions.

Note: See “Specifications” on Page 54 for more information about the scanner’s frequency steps.

FCC NOTICE

Your scanner might cause radio or TV interference even when it is operating properly. To determine whether your scanner is causing the interference, turn off your scanner. If the interference goes away, your scanner is causing it. Try the following methods to eliminate the interference:

- Move your scanner away from the receiver.
- Connect your scanner to an outlet that is on a different electrical circuit from the receiver.
- Contact your local RadioShack store for help.

This device complies with Part 15 of the *FCC Rules*. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Mobile use of this scanner is unlawful or requires a permit in some areas. Check the laws in your area.

SCANNING LEGALLY

Your scanner covers frequencies used by many different groups including police and fire departments, ambulance services, government agencies, private companies, amateur radio ser-

vices, military operations, pager services, and wireline (telephone and telegraph) service providers. It is legal to listen to almost every transmission your scanner can receive. However, there are some transmissions you should never intentionally listen to. These include:

- telephone conversations (cellular, cordless, or other private means of telephone signal transmission)
- pager transmissions
- any scrambled or encrypted transmissions

According to the Electronic Communications Privacy Act (ECPA), you are subject to fines and possible imprisonment for intentionally listening to, using, or divulging the contents of such a transmission unless you have the consent of a party to the communication (unless such activity is otherwise illegal).

This scanner is designed to prevent reception of illegal transmissions, in compliance with the law which requires that scanners be manufactured in such a way as to not be easily modifiable to pick up those transmissions. Do not open your scanner's case to make any modifications that could allow it to pick up transmissions that it is not legal to listen to. Doing so could subject you to legal penalties.

We encourage responsible, legal scanner use.

CONTENTS

Preparation	8
Connecting an Antenna	8
Mounting an Antenna	8
Mounting the Scanner In Your Vehicle	8
Powering the Scanner	9
Using the Scanner as a Base Station	10
Connecting an Extension Speaker	11
Connecting an Earphone/Headphones	12
Connecting the Clone Cable	12
Understanding Your Scanner	13
A Look at the Keypad	13
A Look at the Display	16
Understanding Banks	18
Understanding CTCSS/DCS	18
Understanding Your Scanner's Modes	19
Operation	22
Turning On the Scanner and Setting Squelch	22
Storing Known Frequencies into Channels	22
Storing Text Tags	23
Finding and Storing Active Frequencies	25
Scanning the Channels	27
Manually Tuning a Frequency	28
Deleting Frequencies from Channels	28
Listening To the Weather Band	28
Special Features	30
Using Delay	30
Locking Out Channels, Frequencies, and Trunking IDs	30
Priority	31
Changing the Open/Closed Mode	32
Changing the Receive Mode	33
Changing the Frequency Step	33
Using the Attenuator	34
Turning the Key Tone On and Off	34
Changing the Display Contrast	35
Cloning Programmed Data from Scanner to Scanner	35

Trunking Operation	36
Understanding Trunking	36
Setting Squelch for the Trunking Mode	37
Programming Trunking Frequencies	37
Programming Fleet Maps	39
Talk Group IDs	41
Open and Closed Modes	43
A General Guide to Scanning	44
Guide to Frequencies	44
Guide to the Action Bands	45
Band Allocation	46
Frequency Conversion	50
Troubleshooting	51
Resetting/Initializing the Scanner	52
Care and Maintenance	53
Specifications	54

PREPARATION

CONNECTING AN ANTENNA

You must install an antenna before you can operate the scanner. Your local RadioShack store sells a variety of scanner antennas for both mobile and base-station use. Choose the one that best meets your needs.

When deciding on a mobile or base-station antenna and its location, consider these points.

- The antenna should be as high as possible on a vehicle or a house.
- The antenna and its cable should be as far as possible from sources of electrical noise (ignition systems, gauges, and so on).
- The antenna should be vertical for the best performance.

MOUNTING AN ANTENNA

Once you choose an antenna, follow the mounting instructions supplied with the antenna. Then route the antenna cable to the scanner.

The antenna connector on your scanner makes it easy to use the scanner with a variety of antennas, such as an external mobile antenna or outdoor base station antenna.

Always use 50-ohm coaxial cable, such as RG-58 or RG-8, to connect an

outdoor antenna. For lengths over 50 feet, use RG-8 low-loss dielectric coaxial cable. If your antenna's cable does not have a BNC connector, you will also need a BNC adapter (available at your local RadioShack store).

Follow the installation instructions supplied with the antenna, route the antenna cable to the scanner, then connect it to the **ANT** jack.

Warning: Use extreme caution when you install or remove an outdoor antenna. If the antenna starts to fall, let it go! It could contact overhead power lines. If the antenna touches a power line, contact with the antenna, mast, cable, or guy wires can cause electrocution and death. Call the power company to remove the antenna. DO NOT attempt to do so yourself.


MOUNTING THE SCANNER IN YOUR VEHICLE

Before you mount the scanner, make sure you have all the necessary materials. Then confirm that the scanner fits your vehicle's mounting area. This scanner is a DIN-E size unit that requires a 2-inch high by 6¹¹/₁₆-inch wide by 5¹/₂-inch deep (50 × 170 × 140 mm) mounting area.


Caution: Be sure to avoid obstructions behind the mounting surface.

Follow these steps to mount the scanner in your vehicle.


1. Choose a mounting location, then use the supplied mounting bracket as a template to mark the positions for the mounting screw holes.
2. In the marked positions, drill holes slightly smaller than the supplied screws.
3. Attach the mounting bracket to the mounting location using the supplied screws and lock washers.



4. Attach a rubber washer to both of the mounting bracket's holes.
5. Attach the scanner to the mounting bracket using the supplied mounting knobs.



6. Connect the antenna's cable to the **ANT** jack on the back of the scanner.



Note: If the antenna cable's connector does not fit in the **ANT** jack, you might also need a Motorola-to-BNC antenna plug adapter (available at your local RadioShack store).

POWERING THE SCANNER


You can power your scanner using either the supplied DC power cord or from your vehicle's cigarette lighter socket using an optional DC cigarette lighter power cable.

Cautions:




You must use a power source that supplies 12V DC and delivers at least 500 mA. Its center tip must be set to positive and its plug must fit the scanner's **DC 13.8V** jack. The supplied DC power cord meets these specifications. Using a power cord that does not meet these specifications could damage the scanner or the adapter.

- Always connect the adapter or DC power cord to the scanner before you connect it to the power source. When you finish, disconnect the adapter or DC power cord from the power source before you disconnect it from the scanner.
- For added safety and to protect your scanner, disconnect the cable from your vehicle battery's negative (-) terminal before you begin.



Follow these steps to connect the supplied DC power cord.

1. Connect the power cord's black wire to a chassis ground, such as a metal screw attached to a metal part of the vehicle's frame. Be sure that the screw is not insulated from the frame by a plastic part.
2. Connect the power cord's red wire (with in-line fuse) to a source of voltage that turns on and off with the ignition switch, such as a spare accessory terminal in your vehicle's fuse box.



3. Insert the power cord's barrel plug into the **DC 13.8V** jack on the back of the scanner.



4. Reconnect the cable to the vehicle battery's negative (-) terminal.

To power the scanner from a vehicle's 12V power source (such as a cigarette-lighter socket), you need a 12V, 500-mA DC cigarette-lighter adapter (not supplied), available at your local RadioShack store.

To connect an optional DC cigarette-lighter power cable, insert its barrel plug into the **DC 13.8V** jack on the back of the scanner, then plug the power cable into your vehicle's cigarette lighter socket.

Note: If you use a cigarette-lighter power cable and your vehicle's engine is running, you might hear electrical noise from the engine while scanning. This is normal.

USING THE SCANNER AS A BASE STATION

You can place this scanner on a desk, shelf, or table to use it as a base station.

Using Standard AC Power

To power the scanner from an AC outlet, you need an AC adapter (not supplied) with a 5.5 mm outer diameter/2.1 mm inner diameter tip.

Cautions:




You must use a Class 2 power source that supplies 12V DC and delivers at least 500 mA. Its center tip must be set to positive and its plug must fit the scanner's **DC 13.8V** jack. Using an adapter that does not meet these specifications could damage the scanner or the adapter.

- Always connect the AC adapter to the scanner before you connect it to AC power. When you finish, disconnect the adapter from AC power before you disconnect it from the scanner.

1. Connect the adapter's 5.5 mm outer diameter/2.1 mm inner diameter tip to the adapter's cord and set the barrel plug's tip to positive.
2. Insert the adapter's barrel plug into the **DC 13.8V** jack on the back of the scanner.


3. Plug the adapter into a standard AC outlet.



CONNECTING AN EXTENSION SPEAKER

In a noisy area, an amplified extension speaker (available at your local RadioShack store) positioned in the right place might provide more comfortable listening.


Plug the speaker cable's 1/8-inch (3.5-mm) plug into your scanner's **EXT SP** jack.



Note: Connecting an external speaker disconnects the scanner's internal speaker.

CONNECTING AN EARPHONE/HEADPHONES

For private listening, you can connect an earphone or headphones with a $\frac{1}{8}$ -inch (3.5-mm) plug to the **EXT SP** jack on the back of the scanner. (Your local RadioShack store carries a wide selection of earphones and headphones). This automatically disconnects the internal speaker.



Listening Safely

To protect your hearing, follow these guidelines when you use an earphone or headphones.

- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Set **VOLUME** to the lowest setting before you begin listening. After you begin listening, adjust **VOLUME** to a comfortable level.

- Once you set **VOLUME**, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

CONNECTING THE CLONE CABLE

You can transfer the programmed data to and from another Cat. No. 20-196 or Cat. No. 20-522 scanner using the supplied clone cable. Connect the cable between each scanner's **PC/IF** jacks. See "Cloning Programmed Data from Scanner to Scanner" on Page 35. You can also upload or download the programmed data to or from a PC using an optional PC interface kit available through your local RadioShack store.

UNDERSTANDING YOUR SCANNER

Once you understand a few simple terms used in this manual and familiarize yourself with your scanner's features, you can put the scanner to work for you. You simply determine the type of communications you want to receive, then set the scanner to scan them.

A **frequency** is the tuning location of a station (expressed in kHz or MHz). To find active frequencies, you can use the **search** function.


You can also search the **service-search banks**, which are preset groups of frequencies categorized by type of service.

When you find a frequency, you can store it into a programmable memory location called a **channel**, which is grouped with your other channels in a **channel-storage bank**. You can then **scan** the channel-storage banks to see if there is activity on the frequencies stored there. Each time the scanner finds an active frequency, it stays on that channel until the transmission ends.

A LOOK AT THE KEYPAD

Your scanner's keys might seem confusing at first, but this information should help you understand each key's function.

Note: Some of the scanner's keys perform more than one function and are marked with more than one label. The steps in this Owner's Manual show only the label on the key appropriate to the action being performed.



SCAN — scans through the programmed channels or ID code.

WX — scans through the 7 preprogrammed weather channels.

ATT (attenuate) — turns attenuation on to reduce the scanner's sensitivity, or turns it off to increase it.

STEP — changes the frequency step or displays the step frequency during a search.

MODE — changes the receive mode.

PRI (priority) — sets and turns the priority function on or off.

TEXT — lets you input text.

TUNE — tunes a frequency along with ▲ or ▼.

SEARCH — lets you search the ten search banks.

MAN — stops scanning and lets you directly enter a channel number.

FUNC — lets you access various functions by pressing this key along with other keys.

▲ or ▼ — selects the search direction during a search or while tuning to a frequency.

1/DELAY — enters a 1, programs a 2-second delay for the selected channel/search bank, or inputs characters 0 through 9.

2/ABC — enters a 2 or inputs characters A, B, or C.

3/DEF — enters a 3 or inputs characters D, E, or F.

4/GHI — enters a 4 or inputs characters G, H, or I.

5/JKL — enters a 5 or inputs characters J, K, or L.

6/MNO — enters a 6 or inputs characters M, N, or O.

7/PQRS — enters a 7 or inputs characters P, Q, R, or S.

8/TUV — enters a 8 or inputs characters T, U, or V.

9/WXYZ — enters a 9 or inputs characters W, X, Y, or Z.

0 — enters a zero or inputs characters ., -, #, _, @, +, *, &, /, ', \$, %, !, ^, (,), ?, →, ~, and ^.

● — enters a decimal point (necessary when programming frequencies), space, or hyphen (in Motorola type I code setting).

ENTER —enters frequencies, text, and so on.



TRUNK — stores the trunking ID code or holds the trunking ID while scanning.

L/OUT (lockout) — lets you lock out a selected channel, skip a specified frequency during search, or lock out a selected ID code.

CLEAR — clears an incorrect entry.

PROG (program) — programs frequencies into channels.

A LOOK AT THE DISPLAY



If you enter the ID text tag in an ID code, the scanner displays it instead of the ID code and ↯.

```

012••56789
+++••+----+
Scanning...
Priority OFF

```

Scan Mode

- Bank Off
- + Selected for Scanning in Open Mode
- Selected for Scanning in Closed Mode


```

012345••89
Search up...
Priority OFF


```

Search Mode

6 and 7 are turned off



Search Mode



Search Mode

UNDERSTANDING BANKS

Channel Storage Banks

To make it easier to identify and select the channels you want to listen to, channels are divided into 10 banks (0–9) of 50 channels (00 to 49) each. Use each channel-storage bank to group frequencies, such as those used by the police department, fire department, ambulance services, or aircraft (see “Guide to the Action Bands” on Page 45). For example, the police department might use four frequencies, one for each side of town. You could program the police frequencies starting with 000 (the 1st channel in bank 0) and program the fire department frequencies starting with 100 (the 1st channel in bank 1). The first digit identifies the bank (0–9). The second and third digits identify the channel within the bank (00–49).

Search Banks

This scanner is able to search 10 search banks. You can also replace a bank with one of the preprogrammed service bands. (For the default setting, see “Searching a Preprogrammed Frequency Range” on Page 25).

UNDERSTANDING CTCSS/DCS

Continuous Tone Coded Squelch System (CTCSS) and Digital Coded Squelch (DCS) are two methods used to prevent interference by other radio communications. Your scanner can receive transmissions that use these codes.

When your scanner receives a CTCSS transmission, **PL** (private line) appears. When your scanner receives a DCS transmission, **DPL** (digital private line) and a 3-digit code appear.

PL Codes

PL codes are low-frequency audio tones that are used to differentiate different users on the same channel. PL codes appear according to the EIA standard CTCSS tones, and range from 67.0 Hz to 254.1 Hz. PL codes are displayed directly as a frequency.

DPL Codes

DPL codes are similar to PL codes, except they might be transmitted as either tones or digital codes. Although there are as many as 4096 DPL codes, only about 100 are actually used.

DPL codes appear in the format **Dxxx**, where **xxx** is an octal code.

UNDERSTANDING YOUR SCANNER'S MODES

Open and Closed Modes

You can set your scanner to change the way it receives signals. These settings, called *open mode* and *closed mode*, affect how the scanner receives signals from communications systems that use some type of closed squelch (such as PL, DPL, LTR, MOT, and ED systems). You can set each of the scanner's channel storage banks to open or closed mode.

In open mode, the scanner scans signals transmitted in all systems. In closed mode, the scanner scans signals transmitted only under the following conditions:

- When the signals are in the FM mode.
- When the signals are in the LT, MO, or ED mode *and* the signal's ID code matches the programmed ID code.
- When the signals are in the PL or DPL mode *and* the signal's ID code matches the programmed ID code.

Note: When the signals are in the PL or DPL mode, the scanner receives all signals on a channel when the ID code is set to NONE.

You can also select the users or talk groups you want the scanner to receive in closed mode.

When you set a channel storage bank to open mode, + (open) appears under the bank's number while scanning. When you set a channel storage bank to closed mode, - (closed) appear under the channel storage bank's number while scanning. Or, **OPEN** or **CLOSED** appears while the scanner is in manual mode or while the scanner is receiving a signal during scanning.

See "Changing the Open/Closed Mode" on Page 32 for more information about setting the open and closed modes.

LTR (E. F. Johnson) Mode

You can set your scanner so it decodes the talk group IDs used with LTR systems. This setting is called the *LTR mode*.

LTR systems are trunking systems used primarily by business or private communications service providers, such as taxicabs, delivery trucks, and repair services. These systems encode all trunking information as digital subaudible data that accompanies each transmission. Users on an LTR system are assigned to specific talk groups, which are identified by the radio as six-digit numbers. These numbers are in the form **AHHUUU**, where:

A = Area code (0 or 1)

H = Home repeater (01 through 20)

U = User ID (000 through 254)

When the scanner receives a transmission on a channel set to the LTR mode, it first decodes the LTR data included with the transmission. In the open mode, the scanner stops on the transmission and displays the talk group ID on the bottom line of the display. In the closed mode, the scanner only stops on the transmission if the LTR data matches a talk group ID that you have stored in the bank's talk group ID list and have not locked out.

LTR systems are frequently programmed so that each radio has a unique ID code.

Motorola Mode

You can set your scanner so it decodes the talk group IDs used with Motorola trunking systems. This setting is called the *Motorola mode*.

Motorola systems are trunking systems used primarily by business and public safety groups to efficiently allocate a small number of frequencies (as few as 5) to many groups of users (as many as several thousand). To do this, each group of users in the system is assigned to a specific talk group. For example, the east side patrol officers might all be assigned to talk group 2160. One channel in the system is continuously transmitting data that identifies which talk groups are active on which channel. In addition, this talk group information is also transmitted as subaudible data on each active channel.

When the scanner receives a transmission on a channel set to the Motorola mode, it first decodes the talk group ID data included with the transmission. In the open mode, the scanner stops on the transmission and displays the talk group ID on the bottom line of the display. In the closed mode, the scanner only stops on the transmission if the talk group ID matches a talk group ID that you have stored in the bank's talk group ID list and have not locked out.

Motorola trunking systems come in three categories: *Type I*, *Type II*, and *Type III Hybrid*. Each category displays and uses talk group IDs in slightly different ways.

Motorola Type I IDs are in the form **FFF-SS**, where:

FFF = Fleet ID

SS = Subfleet ID

Type I systems are usually organized with different user groups assigned to different fleets. For example, a valid fleet/subfleet ID identifying all detectives within a police department might be **000-12**, where **000** identifies all police users and **12** identifies the Detective division.

To properly map the raw Type I data to the correct fleet-subfleet format, you must program the correct fleet map into the scanner. Fleet map information is widely available on the Internet for most Type I systems in use.

Type II system talk groups are identified by a 5-digit number. Valid talk group IDs are divisible by 16. If you try to enter an invalid talk group ID, the scanner rounds the ID down to the next valid ID.

Type I/II hybrid systems use both fleet-subfleet and 5-digit formats for talk group IDs.

Note: If the scanner decodes control channel data while receiving transmissions from a Motorola trunking system, **CNTRL** appears on the bottom line of the display. For example:

MO01 ↯ • D • - MO 866.1625 MHz Bank 0 Ch 01 MOT: CNTRL

EDACS Mode

You can set your scanner so it decodes the talk group IDs used with EDACS (GE/Ericsson) trunking systems. This setting is called the *EDACS mode*.

EDACS systems are trunking systems used primarily by business or private communications service providers, as well as by some public safety organizations. EDACS systems transmit active talk group information only on a dedicated control channel.

EDACS frequencies are organized in a specific order. Each frequency is assigned a Logical Channel Number (LCN). For the scanner to correctly switch to an active frequency, you must program the frequencies in LCN order, starting with Memory 01. EDACS talk group IDs are entered as a 4-digit decimal number from 0000 to 4096.

When there is activity on an EDACS system, that information is sent out on the control channel. The scanner decodes the ID for the active talk group. In the open mode, the scanner then goes to the transmission and displays the talk group ID on the bottom line of the display. In the closed mode, the scanner only goes to transmissions that have IDs that match a talk group ID that you have stored in the bank's talk group ID list and have not locked out.

Because EDACS scanning requires clear reception of the control channel at all times, EDACS systems tend to have a smaller usable area. An external antenna can greatly improve EDACS scanning in a fringe area. If you are having trouble scanning an EDACS system, try manually selecting the data channel. If you are getting good reception, the scanner will indicate talk group **CTL-01**. Try changing your location or using an outdoor antenna to improve reception.

OPERATION

TURNING ON THE SCANNER AND SETTING SQUELCH

1. Turn **SQUELCH** fully counterclockwise until the indicator points to **MIN**.
2. To turn on the scanner, turn **VOLUME** clockwise. **Welcome to Multi-System Trunking** appears. Then, after about 3 seconds, you hear a hissing sound.
3. Turn **SQUELCH** clockwise and leave it set to a point just after the hissing sound stops.
4. To turn off the scanner, turn **VOLUME** counterclockwise to **OFF**.

Notes:

- The scanner does not scan if there are no frequencies stored in channels. If the scanner does not scan and you have already stored frequencies in channels, turn **SQUELCH** further clockwise.
- If the scanner picks up unwanted, partial, or very weak transmissions, turn **SQUELCH** clockwise to decrease the scanner's sensitivity to these signals. If you want to listen to a weak or distant station, turn **SQUELCH** counterclockwise.
- If **SQUELCH** is adjusted so you always hear a hissing sound, the scanner will not scan properly.

- To ensure the scanner operates properly while in the trunking mode, we suggest you set **SQUELCH** using the above steps, even if the scanner is automatically muted.

STORING KNOWN FREQUENCIES INTO CHANNELS

Good references for active frequencies are the RadioShack *Police Call Guide including Fire and Emergency Services*, *Official Aeronautical Frequency Directory*, and *Maritime Frequency Directory*. We update these directories every year, so be sure to get a current copy. You can also quickly and easily program your scanner by using *Scanner Data Manager* software, available at your local RadioShack store.

Follow these steps to store frequencies into channels.

1. Press **MAN**, enter the bank number (0–9) and the channel number (00–49) where you want to store a frequency, then press **MAN** again. **M** and the channel number appear.
2. Press **PROG**. **M** changes to **P**.
3. Use the number keys and **•** to enter the frequency (including the decimal point) you want to store.

If you make a mistake, hold down **CLEAR** for about a second to delete a single digit or about 2 seconds to delete all digits.

-
-
4. Press **ENTER** to store the frequency into the channel.

Notes:

- If you made a mistake in Step 3, **Invalid Freq** appears and the scanner beeps when you press **ENTER**. Simply start again from Step 3.
 - Your scanner automatically rounds the entered frequency down to the nearest valid frequency. For example, if you enter a frequency of 151.473, your scanner accepts it as 151.470.
 - The scanner automatically pauses 2 seconds on a channel after a transmission ends before it proceeds to the next channel. To turn off delay, press **FUNC** then **DELAY**. (See “Using Delay” on Page 30).
5. If necessary, change the receive mode (see “Changing the Receive Mode” on Page 33). If you select PL or DPL mode, enter the PL or DPL code by pressing **STEP** (to move through the codes upward) or **FUNC** then **STEP** (to move through the codes downward).
 6. To program the next channel in sequence, press **PROG** and repeat Steps 3 through 5.

STORING TEXT TAGS

You can customize your scanner by storing text tags (up to 12 characters)

for easy identification of channel transmissions, trunk IDs, or banks.

Assigning a Text Tag to a Channel

1. Press **MAN**, enter the bank number or channel number where you want to enter the text, then press **MAN** again. **M** and the channel number appear at the upper left corner of the display (for example: M100).
2. Press **PROG**. **M** changes to **P** on the display.
3. Press **TEXT**. The cursor appears at the third line on the display.
4. Enter the desired text using the number keys (see “Text Input Chart” on Page 24).
Note: If you make a mistake, press **▼** or **▲** to move to the character you want to change.
5. Press **ENTER** to input the text.

Assigning a Text Tag to a Bank

1. Select a channel within the desired bank by pressing **MAN** and entering the 3-digit bank number (000 for bank 0 or 200 for bank 2, for example). Press **MAN** again, then press **PROG**.
2. Press **FUNC** then **6**. The cursor appears at the 3rd line on the display.

3. Enter the desired text using the keypad then press **ENTER**.

Note: If the channel is programmed for PL, DL, LT, MO or ED mode, the scanner displays the ID number from the bank name.

Text Input Chart

Press	To Enter a Character from this Group
1	1, 2, 3, 4, 5, 6, 7, 8, 9, 0
2	A, B, C, a, b, c
3	D, E, F, d, e, f
4	G, H, I, g, h, i
5	J, K, L, j, k, l
6	M, N, O, m, n, o
7	P, Q, R, S, p, q, r, s
8	T, U, V, t, u, v
9	W, X, Y, Z, w, x, y, z
0	., -, #, _, @, +, *, &, /, ', \$,%!, ^, (,),?, →, ` , ^
.	Space
CL	Back Space

To access the numbers, after you press **FUNC** and **6**, press **1** then the desired number.

To enter a lowercase character or a character from the second set for key **0**, press **0** then **FUNC**.

For example, input "HAM 6m" as follows:

1. "H" is the second letter associated with 4 on the keypad. Press **4** then press **2**.
2. "A" is the first letter associated with 2 on the keypad. Press **2** then press **1**.
3. "M" is the first letter associated with 6 on the keypad. Press **6** then press **1**.
4. "space" Press **.**
5. "6" is the sixth number associated with 1 on the keypad. Press **1** then press **6**.
6. *m* is the first letter associated with 6 on the keypad. Press **6** and **FUNC** (for the lowercase set) then **1**.

FINDING AND STORING ACTIVE FREQUENCIES

You can search for transmissions within ten ranges of frequencies, called a search bank. The search bank is divided into ten search bands. You can change the bands with the preprogrammed search bands in the scanner. You can also change the search bank's search ranges manually.

Notes:

- You can use the scanner's delay feature while searching the service bank. See "Using Delay" on Page 30.
- The scanner does not search locked-out frequencies while searching ranges.

Searching a Preprogrammed Frequency Range

The scanner contains these preprogrammed search ranges, stored in search banks (0–9).


Search Bank	Search Range (MHz)	Description
0	460–460.625	Police
1	153.725–156.000	Police/Fire
2	462.925–463.175	Medical

Search Bank	Search Range (MHz)	Description
3	118.000–136.00	Aircraft
4	156.250–157.425	Marine
5	866.000–868.9875	800 MHz
6	50.000–54.000	6 Meter Ham
7	144.000–148.000	2 Meter Ham
8	440.000–450.000	70 cm Ham
9	462.550–462.725	User Bank

Follow these steps to select preprogrammed search ranges and search them for active frequencies.

1. Press **SEARCH**. The scanner searches the active search bank.

Current Search Bank



Note: To reverse the search direction, press **▲** or **▼**.

2. Using the number keys, enter the search bank number for each search range you want to select or remove.

3. When the scanner finds an active frequency, it stops searching. To save the frequency into a channel in the channel storage bank (bank 9 only), press **FUNC** then **ENTER**. **Stored @ 9xx** appears on the bottom row of the display (**xx** is the channel number). Press **▲** or **▼** to continue searching for additional active frequencies.

Notes:

- During a search, you can manually change the band mode or frequency step. See “Changing the Receive Mode” on Page 33 or “Changing the Frequency Step” on Page 33.
- If channel storage bank 9 does not contain any empty channels, **Bank 9 full.** appears on the display’s lower line.
- To pause the search, press **FUNC** then **TUNE**. To begin searching again, press **SEARCH**.

Storing a Frequency to a Specified Channel


1. When the scanner stops on the desired frequency, press **FUNC**.
2. Press **TUNE**.
3. Press **MAN**.
4. Select the desired channel using a number key then press **MAN** again.
5. Press **PROG**.
6. Press **FUNC** then **TUNE** to store the frequency.

7. If desired, press **SEARCH** to return to the search mode.


Changing a Search Range with a Preprogrammed Range

You can replace the search range with one of the preprogrammed ranges.

1. Press **FUNC** then **SEARCH** to enter search program mode. **PSR** and the search bank number of the current range appear at the display’s upper left corner.



2. Press **▲** or **▼** to select the search bank you want to replace.
3. Press **FUNC** then **5. ?SR** and the search bank number appear at the display’s upper left corner.



Note: If you do not press **5** within about 3 seconds after you pressed **FUNC**, the scanner stops search program mode. Start over at Step 1.

-
-
4. Press ▲ or ▼ to select the preprogrammed search range.
 5. Press **ENTER** to replace the search range.

Manually Changing a Search Range

1. Press **FUNC** then **SEARCH** to enter search program mode. **PSR** and a search bank number appear at the display's upper left corner.
2. Press ▲ or ▼ to select the desired search bank number.
3. Use the number keys to enter the lowest frequency range you want to search, then press **ENTER** to store the frequency.
4. Use the number keys to enter the highest frequency range you want to search, then press **ENTER** again to store the frequency.

Notes:

- If you enter a higher frequency, then enter a lower frequency, the scanner automatically exchanges the frequencies on the display. It displays the lowest frequency first and the highest frequency second.
- You cannot search more than one frequency band at a time. When manually setting search ranges, if you enter frequencies that are in different bands, the

scanner does not accept the entry.

5. To assign a name to the search range, press **TEXT** twice, then enter the name. If you want to edit existing text, repeatedly press ▲ or ▼ to move the cursor across the text. Enter the appropriate text and press **ENTER**.

SCANNING THE CHANNELS

To begin scanning channels or to start scanning again after monitoring a specific channel, press **SCAN**.

Note: You must store frequencies into channels before the scanner can scan them. The scanner does not scan empty channels.

The scanner scans through all channels (except those you have locked out) in the active banks (see "Turning Channel-Storage Banks Off and On" and "Locking Out Channels, Frequencies, and Trunking IDs" on Page 30).

Turning Channel-Storage Banks Off and On

To turn off banks while scanning, press the bank's corresponding number key until the bank's number disappears. The scanner does not scan any

of the channels within the banks you have turned off.

Notes:

- You cannot turn off all banks. There must be at least one active bank.
- You can manually select any channel in a bank, even if the bank is turned off.

To turn on banks while scanning, press the bank's corresponding number key until the bank's number appears.

MANUALLY TUNING A FREQUENCY

1. Press **TUNE**.
2. Use the number keys to enter the frequency.
3. Press **ENTER**.
4. Press **▲** to move up one tuning step. Press **▼** to move down one tuning step. To move up or down in 1 MHz increments, press **FUNC** then **▲** or **▼**.

To save the frequency into a channel (bank 9 only), press **FUNC** then **ENTER**. **Stored @ 9xx** appears (**xx** channel number).

When the scanner stops on a frequency while searching, press **FUNC** then **TUNE**.

Notes:

- You cannot change the step frequency while tuning.
- You can change the receiving mode while tuning.

DELETING FREQUENCIES FROM CHANNELS

1. Press **MAN**.
2. Use the number keys to enter the channel containing the frequency you want to delete.
3. Press **MAN** again.
4. Press **PROG** to enter the program mode. **M** changes to **P** on the display.
5. Press **FUNC**.
6. Press **CLEAR**. The frequency number changes and the display shows **0.0000 MHz**.

LISTENING TO THE WEATHER BAND

The FCC (Federal Communications Commission) has allocated channels for use by the National Oceanic and Atmospheric Administration (NOAA). Regulatory agencies in other countries have also allocated channels for use by their weather reporting authorities.

NOAA and your local weather reporting authority broadcast your local forecast and regional weather information on one or more of these channels.

Listening to a Weather Channel

To hear your local forecast and regional weather information, press **WX**. Your scanner scans through the weather band then stops within a few seconds on the strongest weather broadcast.

Displaying Weather Messages

The weather service precedes each weather alert with a digitally-encoded SAME signal, then a 1050 Hz tone. You can set the scanner so, if you are monitoring a weather channel with a digitally-encoded SAME signal when an alert is broadcast, the scanner will decode and display the SAME message, showing the type of alert being broadcast (or **Unknown Message** if it does not recognize the event code).

To set the scanner to decode and display SAME messages, press **FUNC** then **WX** while you listen to the weather channel. **DIG WX STBY** and **Cancel: F + WX** appear.

To set the scanner out of the **SAME** standby mode, press **FUNC** then **WX** again. **DIG WX STBY** disappears.

Notes:

- The scanner does not display the actual location referenced by SAME messages. It uses only the message portion of the SAME signal.
- Your scanner can also receive weather alert tones (see “Priority” on Page 31).

SPECIAL FEATURES

USING DELAY

Many agencies use a two-way radio system that might have a period of 2 or more seconds between a transmission and a reply. To keep from missing a reply, the scanner automatically pauses 2 seconds on a channel after a transmission ends before it proceeds to the next channel.

To turn delay on or off, press **FUNC** then **DELAY**.

LOCKING OUT CHANNELS, FREQUENCIES, AND TRUNKING IDS

You can scan existing channels or search frequencies faster by locking out channels or frequencies that have a continuous transmission, such as a weather channel.

Locking Out Channels

To lock out a channel while scanning, press **L/OUT** when the scanner stops on the channel. Or select the channel then hold down **L/OUT** until **L** appears.

Notes:

- You can still manually select locked-out channels.
- If you lock out a channel that is set to a Motorola trunking mode while using the subaudible decoding

mode, the lockout is removed when power is disconnected then reapplied to the scanner. This makes it easy to temporarily lock out trunking data channels.

To remove the lockout from a channel, manually select the channel and press **L/OUT** until **L** disappears.

Reviewing the Locked-Out Channels

To review all channels that are locked out, first press **MAN** then press **FUNC** then **L/OUT** to view each locked-out channel. When you finish reviewing locked-out channels, press **MAN**.

Locking Out Frequencies

To lock out a frequency during a search, press **L/OUT** when the scanner stops on the frequency. The scanner locks out the frequency then continues searching.

Notes:

- You can lock out as many as 50 frequencies in each bank. If you try to lock out more, **Memory full!** appears.
- If you lock out all frequencies in one search bank and only that search bank is activated, **Search up... All ranges locked out!** appears and the scanner does not search. Select a different bank or unlock some frequencies.

Reviewing Locked-Out Frequencies

Follow these steps to review the frequencies within a search bank that you locked out.

1. Press **SEARCH** to start searching.
2. Press **FUNC** then **L/OUT**. The first locked-out frequency in the selected search bank appears. If the search bank has no locked-out frequency, **L/O list is empty**. appears.
3. Press **FUNC** then **▲** to select a search bank and begin the search for locked-out channels within that bank.
4. Repeatedly press **▲**. The scanner displays all locked-out frequencies within the bank.

SL-1···D·+PL
155.5800 MHz

Clearing a Locked-Out Frequency

To clear a locked-out frequency, select that frequency then press **CLEAR**.

The frequency is unlocked and **Un-locked** appears for about 2 seconds. Then the next locked-out frequency appears. If all locked out

frequencies are cleared within a bank, **L/O list is empty** appears.

Clearing All Locked-Out Frequencies in a Search Bank

1. Press **FUNC** then **SEARCH**.
2. Repeatedly press **▲** or **▼** to select a search bank.
3. Press **FUNC** then **4. Confirm list clear? 1=YES Press other key for NO.** appears.
4. Press **1** to clear all locked-out frequencies, or press any other key to cancel clearing. **List cleared** appears for about 2 seconds if you press **1**.
5. Press **SEARCH** to continue searching.

PRIORITY

The priority feature lets you scan through channels and still not miss important or interesting calls on a channel you select. When a channel is selected as the priority channel and priority is turned on, the scanner checks that channel every 2 seconds. If there is activity on the channel, the scanner stays on the channel until the activity stops.

The scanner is preset to select Channel 00 in Bank 8 as the priority channel. You can program a different channel (including a weather channel) as the priority channel.

Notes:

- The scanner does not stay on the priority channel while the scanner is receiving trunking frequencies.
- If you program a weather channel as the priority channel, the scanner stays on that channel only when it detects the weather alert tone.
- The scanner cannot set a channel as the priority channel if the channel's receive mode is **LTR**, **MOT**, or **ED**.

Follow these steps to program a channel as the priority channel.

1. Press **MAN**.
2. Use the number keys to enter the channel number you want to program as the priority channel, then press **MAN**.
3. Press **FUNC** then **PRI**. **Pri** appears to the right of the frequency.

Follow these steps to program a weather channel as the priority channel.

1. Press **WX**.
2. Select the weather channel you want to program as the priority channel.
3. Press **FUNC** then **PRI**. **Pri** appears to the right of the frequency.

To turn on the priority feature, press **PRI** while scanning. **Priority ON** (or **Priority WX** if you set the priority to a weather channel) appears for about 3 seconds then **P** appears. The scanner checks the priority channel every 2 seconds and stays on the channel if there is activity (or if it detects a weather alert tone if a weather channel is the priority channel), and **Pri** appears and **S** or **M** changes to **P**.

To turn off the priority feature, press **PRI**. **Priority OFF** appears and **P** disappears.

Notes:

- If you program a weather frequency into the priority channel and the scanner detects a weather alert tone on that frequency, the scanner sounds the alert tone.
- The scanner always monitors the priority channel even if the bank it is contained in is set to closed mode (see "Changing the Open/Closed Mode").

CHANGING THE OPEN/ CLOSED MODE

You can set each of the scanner's banks to open mode or closed mode. When a bank is set to open mode, the scanner receives all transmissions on the frequencies in that bank. When a bank is set to closed mode, the scan-

ner receives transmissions only when a preset ID code is also transmitted, and the ID code appears. In closed mode, the scanner does not receive transmissions if they do not have an ID code or if the ID code does not match the preset ID code.

Note: You can set AM and FM frequencies within banks to open or closed mode.

Follow these steps to select a bank and change it to open or closed mode.

1. Press **MAN**.
2. Press **FUNC** then repeatedly press ▲ or ▼ to select the bank you want to change.
3. Press **FUNC** then **2. Bank OPEN** or **Bank CLOSED** appears. Then the tenth digit from the left at the top line of the display changes from + to – or vice versa.

CHANGING THE RECEIVE MODE

The scanner is preset to the most common AM or FM receive mode for each frequency range.

The preset mode is correct in most cases. However, some amateur radio transmitters and trunked systems do not operate in the preset mode. If you try to listen to a transmission when the scanner is not set to the correct receive mode, the transmission might sound weak or distorted.

If you want to listen to private line or trunking transmissions in closed mode, you might have to change the receive mode.

To change the receive mode, repeatedly press **MODE**. The receive mode changes as follows:

Display	Description
AM	AM Mode
FM	FM Mode
PL	FM Mode, Private Line (with 67.0–254.1 Hz PL code)
DL	FM Mode, Digital Private Line (with 3-digit DPL code)
LT	FM Mode, LTR Trunking System (with 6-digit ID code)
MO	FM Mode, Motorola Trunking System (with a 4- or 5-digit ID code)
ED	FM Mode, EDACS Trunking System (with 4-digit ID code)

CHANGING THE FREQUENCY STEP

The scanner searches at a preset frequency step for each frequency range. These are the frequency steps your scanner uses for each frequency range.

Range (MHz)	Search Step (kHz)
29.000-54.000	5, 10, 15, 20, 25, 30, 50, 100
108.000-136.9875	12.5, 25, 50, 100
137.000-174.000	5, 10, 15, 20, 25, 30, 50, 100
380.000-512.000	12.5, 25, 50, 100
806.000-823.9875	12.5, 25, 50, 100
849.000-868.9875	12.5, 25, 50, 100
894.000-960.000	12.5, 25, 50, 100

To change the frequency step while moving between frequencies within a search band, repeatedly press **STEP**. Or, follow these steps to change the frequency step within a specific bank.

1. Press **SEARCH**.
2. Select a bank.
3. Turn **SQUELCH** fully counterclockwise until the indicator points to **MIN**.
4. Repeatedly press **STEP** until you reach the desired step.
5. Turn **SQUELCH** clockwise and leave it set to a point just after the hissing sound stops.

USING THE ATTENUATOR

To reduce interference or noise caused by strong signals, you can reduce the scanner's sensitivity to these signals (called *attenuation*). You can set attenuation for each of the scanner's channels.

Note: If you turn on this feature, the scanner might not receive weak signals.

To reduce the scanner's sensitivity on the current channel, repeatedly press **ATT** until **A** appears. To turn off attenuation, press **ATT** again. **A** disappears.

TURNING THE KEY TONE ON AND OFF

Each time you press any of the scanner's keys, the scanner sounds a tone. Follow these steps to turn the scanner's key tone off or on.

1. If the scanner is on, turn **VOLUME** counterclockwise until it clicks to turn the scanner off.
2. Turn **VOLUME** clockwise to turn the scanner on. **Welcome To Multi-System Trunking** appears.
3. While **Welcome To Multi-System Trunking** appears, press **1** to turn on the key tone or **2** to turn it off.

CHANGING THE DISPLAY CONTRAST

1. Press **MAN**.
2. Press **FUNC** then **9**. Use **Up/Down keys to set contrast**. appears on the display.
3. Press **▲** or **▼** to select the desired contrast.
4. Press **ENTER** to store the setting.

CLONING PROGRAMMED DATA FROM SCANNER TO SCANNER

You can transfer the programmed data to and from another RadioShack Cat. No. 20-196 or Cat. No. 20-522 scanner using the supplied clone cable. To clone the data, follow these steps.

1. Turn on both scanners.
2. Connect the supplied clone cable to each scanner's **PC/IF** jack. **CLONE MODE UP to send, remove cable to exit** appears.
3. Press **▲**. **Confirm send data? 1=Yes Press other key for No.** appears.
4. Press **1** to send the data to the other unit or press any other key to cancel the operation.

The scanner sends the data. To exit the clone mode, remove the cable.

TRUNKING OPERATION

The scanner tracks transmissions that use the Motorola® Type I and Type II (such as Smartnet and Privacy Plus) and hybrid analog trunking systems, plus GE/Ericsson (EDACS) and EF Johnson (LTR) type systems, which are extensively used in many communication systems.

Trunking systems allocate a few frequencies to many different users. When the mobile unit transmits a signal, one frequency is chosen from among the allocated frequencies in that trunking system. The user's **ID talk group** is sent with the signal.

To receive trunking signals, you must store all the trunking group frequencies in one bank (see "Storing Known Frequencies into Channels" on Page 22) and input ID codes in the ID memory (see "Finding and Storing Active Frequencies" on Page 25). To listen to the transmission, the mode of the programmed channel must be the same as that of the trunking channel (LT, MO, or ED).

When an ID code is received, the ID list for the bank is searched, and if found, the text name stored for the ID appears. If not found, scanning resumes immediately unless the bank is in open trunking mode.

Note: There might be more than one talk group transmitting at a time in some Motorola trunking systems. If you set the scanner to manually tune in Motorola trunking mode, you will hear the talk group on that channel, but the display will alternate between all active IDs.

Trunking group frequencies are included in the supplied *Police Call Trunking Guide*. Frequency fleet map and talk group information is also widely available on the Internet, at www.trunkscanner.com for example.

UNDERSTANDING TRUNKING

In the past, groups that transmit frequently, such as police departments, could transmit on only a few frequencies. This resulted in heavy traffic and often required 2-way radio users to wait for a specific frequency to clear before transmitting. Trunked systems allow more groups of 2-way radio users to use fewer frequencies. Instead of selecting a specific frequency to transmit on, a trunked system chooses one of several frequencies when the 2-way radio user transmits. The system automatically transmits the call on that frequency, and also sends a code that identifies that 2-way radio user's transmission on a control channel.

This scanner lets you easily hear both the call and response transmissions for that 2-way radio user and therefore follow the conversation. For EDACS and Motorola (above 806 MHz range), the scanner monitors the control channel between each transmission to identify talk groups. For some Motorola (under 512 MHz range) and LTR systems, the scanner uses the subaudible data sent with each transmission to identify talk groups.

SETTING SQUELCH FOR THE TRUNKING MODE

Your scanner automatically mutes the audio during trunk scanning when it decodes control channel data. However, we recommend you turn **SQUELCH** clockwise and leave it set to a point just after the hissing sound stops. This lets the scanner quickly acquire the data channel.

PROGRAMMING TRUNKING FREQUENCIES

You program trunking frequencies just like non-trunked frequencies, except that you must store the appropriate mode (MO, ED, or LT) with each frequency.

Notes:

- You can store only one trunked EDACs and Motorola channel in a bank. You can, however, mix LTR and conventional channels in a bank.
- If you are scanning UHF trunking frequencies under the 512 MHz range using subaudible data and are not using a base frequency and offset, lock out all data channels. See “Programming Motorola Trunking Systems (UHF-Lo)” on Page 38 and “Locking Out Channels, Frequencies, and Trunking IDs” on Page 30. Turn off the scanner to remove the lockouts.


- If you are programming trunked frequencies for Motorola Type I and hybrid systems, you must first program the fleet map (see “Programming Fleet Maps” on Page 39).
- You must store frequencies using the subaudible trunking method in banks mode by mode.

Follow these steps to program trunked frequencies.

1. Press **PROG** and select the bank, then press **TRUNK** to enter the ID program mode.
2. Repeatedly press **MODE** to select **LT** for EF Johnson, **MO** for Motorola, or **ED** for the EDACS (GE/Ericsson) system to scan. This sets the talk group ID decoding method to be used for the bank.

Notes:

- If you select -- instead of **LT**, **MO**, or **ED**, the scanner does not scan trunked frequencies. Instead, you see:



3. Press **PROG** to enter the program mode.
4. Store the trunking frequencies into subsequent channels in the same

bank (see “Storing a Frequency to a Specified Channel” on Page 26).

5. Repeatedly press **MODE** to select the trunking mode (**LT** for EF Johnson, **MO** for Motorola, or **ED** for the EDACS (GE/Ericsson) system).
6. Press **SCAN**. If the scanner’s receive mode matches the ID mode, **T** appears and the scanner scans the frequencies.

Programming Motorola Trunking Systems (UHF-Lo)

You can program the scanner to receive transmissions in the UHF-Lo band (380–512 MHz) of the Motorola Trunking System. You can receive these transmissions by:

- Checking the trunking system’s base frequency and offset frequency. You must program the system’s base frequency and offset frequency to do this.
- Decoding the subaudible data transmitted with the signals. When you do this, the scanner might detect wrong IDs but you can easily receive trunking frequencies without programming the base and offset frequencies.

Notes:


- Base and offset frequencies vary for each type of trunking system. You can get information about these frequencies for the trunking system you want to scan using

www.trunkscanner.com, other Internet sources, or locally-published guidebooks.

- The scanner automatically decodes subaudible data it receives in the VHF band.
- If you try to enter an offset frequency in the VHF and UHF-Hi bands (137–174 and 806–960 MHz), the scanner will ignore the entry.

Follow these steps to program Motorola trunking frequencies in the UHF-Lo band.

1. Select the bank, then press **PROG** to enter the program mode.
2. Store the base frequency into channel 00 of the bank you selected, then store the trunking frequencies into subsequent channels in the same bank (see “Storing a Frequency to a Specified Channel” on Page 26).
3. Press **TRUNK** then repeatedly press **MODE** to select **MO** (Motorola).
4. Press **FUNC** then **9. 12.5 kHz** (the default offset frequency) appears.



Offset Frequency

- Repeatedly press **FUNC** then **9** to select the offset frequency you want (**12.5 kHz**, **25.0 kHz**, or **50 kHz**).

Note: Offset frequencies above 50 kHz do not appear and are used only for subaudible decoding mode.

- Program the trunking frequencies (see “Programming Trunking Frequencies” on Page 37).

PROGRAMMING FLEET MAPS

If you want to receive a Motorola Type I system, you need to set the fleet map. Fleet maps are included along with other information about Motorola Type I systems at www.trunkscanner.com.

Follow these steps to program a fleet map.

- Press **PROG**.
- Press **TRUNK**.
- For each bank you want to program, repeatedly press **FUNC**, **▲**, or **▼** to select the bank.
- Press **FUNC**.
- Press **8**. You see:

Block 0 size code. Use 15 for type II. S-00

- Enter the size code information supplied with the Type I system information, referring to the instruction that appears on the display. If the information was not supplied, try the following common fleet maps.

BLOCK	Size Code							
	1	2	3	4	5	6	7	8
0	S11	S4	S4	S12	S4	S3	S10	S1
1	S11	S4	S4	—	S4	S10	S10	S1
2	S11	S4	S4	S4	S12	S4	S11	S2

B L O C K	Size Code							
	1	2	3	4	5	6	7	8
3	S11	S4	S4	S4	—	S4	S4	S2
4	S11	S4	S4	S4	S4	S12	S4	S3
5	S11	S4	S4	S4	S4	—	S4	S3
6	S11	S4	S12	S4	S4	S12	S4	S4
7	S11	S4	—	S4	S4	—	S4	S4
B L O C K	Size Code							
	9	10	11	12	13	14	15	16
0	S4	S0	S4	S0	S3	S4	S4	S3
1	S4	S0	S0	S0	S3	S3	S4	S10
2	S0	S0	S0	S0	S11	S10	S4	S10
3	S0	S0	S0	S0	S4	S4	S11	S11
4	S0	S0	S0	S0	S4	S4	S11	S0
5	S0	S0	S0	S0	S0	S4	S0	S0
6	S0	S4	S0	S0	S0	S12	S12	S12
7	S0	S4	S0	S4	S0	—	—	—

7. Press **ENTER** for each entry. If you make a mistake, press **CL** and enter the correct size code.

Note: The default setting of the bank is for Motorola Type II. However, after you set Type I and if you want to return to Type II, enter **15** at Step 6.

8. To confirm the input, repeat Steps 1–6 and press **ENTER**. Each time you press **ENTER**, you confirm the size code. If you find an error, press **CLEAR** and begin again at Step 1.

9. Press **SCAN** to start scanning.

TALK GROUP IDS

You can program up to 100 talk group IDs in each bank. When the scanner stops on a transmission in the LTR, Motorola, or EDACS mode, it checks to see if the ID has been stored. In the closed mode, the scanner only stops on the transmission and displays its text tag if you have stored and not locked out the ID. In the open mode, the scanner always stops on a transmission, but it displays the ID's text tag if you have stored the ID.

Storing Talk Group IDs

To store a talk group ID when scanning, press **TRUNK** when the scanner stops on a transmission. The bottom line changes to **ID#XXXX** indicating that the ID is stored.

Note: When you try to store more than 100 talk group IDs in a bank, **Memory full!** appears. Clear some talk group IDs in order to store new ones (see "Clearing a Talk Group ID" on Page 42).

Follow these steps to manually store talk group IDs or to edit a stored ID.

1. Press **PROG**.
2. Press **TRUNK**.
3. To select the bank you want to store the ID to, repeatedly press **FUNC** and **▲** or **▼**.
4. Repeatedly press **MODE** to select **LT**, **MO**, or **ED**.
5. Enter the talk group ID and press **ENTER**. If necessary, use the decimal point for a hyphen.
6. Press **TEXT** and enter the text tag for the ID and press **ENTER**.
7. To store the next ID memory in sequence, press **▲** and repeat Steps 4 and 5 or 6 to enter more IDs.
8. Press **SCAN** to start scanning.

Note: If you made a mistake in Step 5, **Invalid ID.** appears and the scanner beeps when you press **ENTER**. Start again at Step 5.

Talk Group ID Hold

You can set your scanner to follow a trunking signal that you want to track during scanning. Hold down **TRUNK** for more than 2 seconds. You see:

S208 4 ••D•+MO 850.6625 MHz Bank 2 Ch 08 ID hold ON.

To release **ID hold ON.**, press **SCAN** or **TRUNK**.

Locking Out Talk Groups ID

Note: You can only lock out talk group IDs when the scanner is in the closed mode (see "Open and Closed Modes" on Page 43).

Follow these steps to lock out a talk group ID.

1. Press **PROG**.
2. Press **TRUNK**.
3. Repeatedly press **FUNC** and **▲** or **▼** to move the desired bank.
4. Repeatedly press **▲** or **▼** to select the ID memory.
5. Press **L/OUT** to lock out the ID. **L** appears.
6. To remove the lockout from the trunking ID, manually select the ID memory then repeatedly press **L/OUT** until **L** disappears.

Reviewing Locked-Out Talk Group IDs

Follow these steps to review the talk group IDs you locked out within a bank.

1. Press **PROG** then **TRUNK**.
2. Press **FUNC** then **L/OUT**. The locked-out ID appears on the display. If the ID memory bank has no locked-out ID, you hear a low beep.
3. Press **FUNC** then **▲** or **▼** to select a search bank. Or, simply press **▲** or **▼** to search for any locked-out IDs in a bank.

Note: The scanner checks all frequencies, even if they are not locked out.

Clearing a Talk Group ID

1. Press **PROG** then **TRUNK**.
2. Repeatedly press **FUNC** and **▲** or **▼** to move the desired bank.
3. Repeatedly press **▲** or **▼** to select the ID memory.
4. Press **FUNC** then **CLEAR**.

Clearing All Talk Group IDs in One Bank

You can clear all talk group IDs within a bank. This lets you quickly delete all talk group IDs from a bank if, for example, you want to use the bank to store a different set of talk group IDs.

1. Press **PROG**.
2. Press **TRUNK** to enter a talk group ID memory mode.
3. Repeatedly press **FUNC** and **▲** or **▼** to select a talk group ID bank.
4. Press **FUNC** then **3. Confirm list clear ?1=YES Press other key for NO.** appears.
5. Press **1** to clear all talk group IDs within a bank. **Please wait** then **List cleared** appear and the scanner returns to the talk group ID memory mode.


Note: To cancel the deletion, press any key except **1**.

OPEN AND CLOSED MODES

When set to the open mode, the scanner only uses the ID list to look up ID text tags and stops on any ID code.

When set to the closed mode, the scanner stops only on signals that have an ID code which is found in the ID list for the bank.

Note: When you select a channel manually, any transmission opens squelch, regardless of the current mode.



The open or closed mode is set in each channel storage bank. + or – appears under the channel storage bank’s number while scanning. Or, the status display shows the **OPEN/CLOSED** mode at the top line while the scanner is in manual mode or while the scanner is receiving a signal during scanning.

When no ID code is programmed into the scanner, it receives the signal in PL, DPL, LTR, MOT, or ED mode.

Mode	Open	Closed
PL and DPL	Accepts any PL and DPL.	Accepts only the PL or DPL stored in the channel.
MOT/ED/LTR	Stops on any transmission. If the ID is stored, displays the text tag, otherwise displays the talk group ID.	Only stops on transmission if the ID is stored. Displays the text tag.

Changing the Open/Closed Mode

1. Press **MAN**.
2. Press **FUNC** then ▲ or ▼ to select the channel-storage bank.
3. Press **FUNC** then 2. **Bank OPEN** or **Bank CLOSED** appears.

After that message disappears, the 10th right most digit at the top of the line of the display changes from + to – or vice versa.

4. Repeat Steps 2–3 for each bank.

A GENERAL GUIDE TO SCANNING

Reception of the frequencies covered by your scanner is mainly “line-of-sight.” That means you usually cannot hear stations that are beyond the horizon.

GUIDE TO FREQUENCIES

National Weather Frequencies

162.400	162.475	162.525	162.425
162.500	162.550	162.450	

Birdie Frequencies

Every scanner has birdie frequencies. Birdies are signals created inside the scanner’s receiver. These operating frequencies might interfere with transmissions on the same frequencies. If you program one of these frequencies, you hear only noise on that frequency. If the interference is not severe, you might be able to turn **SQUELCH** clockwise to cut out the birdie. This scanner’s birdie frequencies (in MHz) are:

29.000	32.100	35.940	38.400	39.935
42.975	43.930	47.925	51.915	54.000
108.000	115.8125	123.800	131.7875	139.775
143.770	147.765	150.150	151.760	155.750
159.745	163.740	167.730	171.550	383.3875
387.375	391.375	395.375	403.3625	407.350
411.350	415.3375	419.3375	423.325	427.3125
429.050	431.3125	439.300	443.2875	447.2875
451.275	455.275	459.2625	463.2625	467.250
475.2375	479.2375	483.225	487.225	491.2125
495.2125	499.200	503.200	511.1875	814.700
818.700	898.5625	902.500	906.550	910.5375
918.350	926.3375	930.3375	934.325	938.325
944.050		954.300		960.000

To find the birdies in your individual scanner, begin by disconnecting the antenna and moving it away from the scanner. Make sure that no other nearby radio or TV sets are turned on near the scanner. Use the search function and search every frequency range from its lowest frequency to the highest. Occasionally, the searching will stop as if it had found a signal, often without any sound. That is a birdie. Make a list of all the birdies in your scanner for future reference.

GUIDE TO THE ACTION BANDS

Typical Band Usage (MHz)

VHF Band

Low Range	29.00–50.00
6-Meter Amateur	50.00–54.00
Aircraft	108.00–136.00
U.S. Government	137.00–144.00
2-Meter Amateur	144.00–148.00
High Range	148.00–174.00

UHF Band

Military Aircraft	380.00–384.00
U.S. Government	406.00–420.00
70-Centimeter Amateur	440.00–450.00
Low Range	450.00–470.00
FM-TV Audio Broadcast, Wide Band	470.00–512.00
Public Service	806.00–823.93
Conventional Systems	851.00–856.00
Conventional/Trunked Systems	856.00–861.00
Trunked Systems	861.00–866.00
Public Safety	866.00–868.93
High Range	896.11–902.00
33-Centimeter Amateur	902.00–928.00
Private Trunked	935.00–940.00
General Trunked	940.00–941.00
Fixed Services	941.00–944.00
Studio-to-Transmitter Broadcast Links	944.00–952.00
Private Fixed Services, Paging	952.00–960.00

Primary Usage

As a general rule, most of the radio activity is concentrated on the following frequencies:

VHF Band

Activities	Frequencies (MHz)
2-Meter Amateur Band	144.000–148.000
Government, Police, and Fire	153.785–155.980

Activities

Emergency Services
Railroad

Frequencies (MHz)

158.730–159.460
160.000–161.900

UHF Band**Activities**

70-Centimeter Amateur Band FM
Repeaters
Land-Mobile “Paired” Frequencies
Base Stations
Mobile Units
Repeater Units
Control Stations

Frequencies (MHz)

440.000–450.000
450.000–470.000
451.025–454.950
456.025–459.950
460.025–464.975
465.025–469.975

Note: Remote control stations and mobile units operate at 5 MHz higher than their associated base stations and relay repeater units.

BAND ALLOCATION

To help decide which frequency ranges to scan, use the following listing of the typical services that use the frequencies your scanner receives. These frequencies are subject to change, and might vary from area to area. For a more complete listing, refer to *Police Call Radio Guide including Fire and Emergency Services*, available at your local RadioShack store.

Abbreviations**Services**

AIR	Aircraft
BIFC	Boise (ID) Interagency Fire Cache
BUS	Business
CAP	Civil Air Patrol
CCA	Common Carrier
CSB	Conventional Systems
CTSB	Conventional/Trunked Systems
FIRE	Fire Department
HAM	Amateur (Ham) Radio
GOVT	Federal Government
GMR	General Mobile Radio
GTR	General Trunked
IND	Industrial Services (Manufacturing, Construction, Farming, Forest Products)
MAR	Military Amateur Radio

MARI	Maritime Limited Coast (Coast Guard, Marine Telephone, Shipboard Radio, Private Stations)
MARS	Military Affiliate Radio System
MED	Emergency/Medical Services
MIL	U.S. Military
MOV	Motion Picture/Video Industry
NEW	New Mobile Narrow
NEWS	Relay Press (Newspaper Reporters)
OIL	Oil/Petroleum Industry
POL	Police Department
PUB.	Public Services (Public Safety, Local Government, Forestry Conservation)
PSB	Public Safety
PTR	Private Trunked
ROAD	Road & Highway Maintenance
RTV	Radio/TV Remote Broadcast Pickup
TAXI	Taxi Services
TELB	Mobile Telephone (Aircraft, Radio Common Carrier, Landline Companies)
TELM	Telephone Maintenance
TOW	Tow Trucks
TRAN	Transportation Services (Trucks, Tow Trucks, Buses, Railroad, Other)
TSB	Trunked Systems
TVn	FM-TV Audio Broadcast
USXX	Government Classified
UTIL	Power & Water Utilities
WTHR	Weather

HIGH FREQUENCY (HF) — (3 MHz–30 MHz)

10-Meter Amateur Band (28.0–29.7 MHz)

29.000–29.700 HAM

VERY HIGH FREQUENCY (VHF) — (30 MHz–300 MHz)

VHF Low Band (29.7–50 MHz in 5 kHz steps)

29.700–29.790	IND
29.900–30.550	GOVT, MIL
30.580–31.980	IND, PUB
32.000–32.990	GOVT, MIL
33.020–33.980	BUS, IND, PUB
34.010–34.990	GOVT, MIL
35.020–35.980	BUS, PUB, IND, TELM
36.000–36.230	GOVT, MIL
36.230–36.990	Oil Spill Cleanup, GOVT, MIL
37.020–37.980	PUB, IND
38.000–39.000	GOVT, MIL
39.020–39.980	PUB
40.000–42.000	GOVT, MIL, MARI
42.020–42.940	POL
42.960–43.180	IND
43.220–43.680	TELM, IND, PUB

43.700–44.600 TRAN
 44.620–46.580 POL, PUB
 46.600–46.990 GOVT
 47.020–47.400 PUB
 47.420 American Red Cross
 47.440–49.580 IND, PUB
 49.610–49.990 MIL

6-Meter Amateur Band (50–54 MHz)

50.00–54.00 HAM

Aircraft Band (108–136 MHz)

108.000–121.490 AIR
 121.500 AIR Emergency
 121.510–136.000 AIR

U.S. Government Band (137–144 MHz)

137.000–144.000 GOVT, MIL

2-Meter Amateur Band (144–148 MHz)

144.000–148.000 HAM

VHF High Band (148–174 MHz)

148.050–150.345 CAP, MAR, MIL
 150.775–150.790 MED
 150.815–150.980 TOW, Oil Spill Cleanup
 150.995–151.475 ROAD, POL
 151.490–151.955 IND, BUS
 151.985 TELM
 152.0075 MED
 152.030–152.240 TELB
 152.270–152.480 IND, TAXI, BUS
 152.510–152.840 TELB
 152.870–153.020 IND, MOV
 153.035–153.725 IND, OIL, UTIL
 153.740–154.445 PUB, FIRE
 154.490–154.570 IND, BUS
 154.585 Oil Spill Cleanup
 154.600–154.625 BUS
 154.655–156.240 MED, ROAD, POL, PUB
 156.255–157.425 OIL, MARI
 157.450 MED
 157.470–157.515 TOW
 157.530–157.725 IND, TAXI
 157.740 BUS
 157.770–158.100 TELB
 158.130–158.460 BUS, IND, OIL, TELM, UTIL
 158.490–158.700 TELB
 158.730–159.465 POL, PUB, ROAD
 159.480 OIL
 159.495–161.565 TRAN
 161.580–162.000 OIL, MARI, RTV
 162.0125–162.35 GOVT, MIL, USXX
 162.400–162.550 WTHR
 162.5625–162.6375 GOVT, MIL, USXX
 162.6625 MED

162.6875–163.225	GOVT, MIL, USXX
163.250	MED
163.275–166.225	GOVT, MIL, USXX
166.250	GOVT, RTV, FIRE
166.275–169.400	GOVT, BIFC
169.445–169.505	Wireless Mikes, GOVT
169.55–169.9875	GOVT, MIL, USXX
170.000–170.150	BIFC, GOVT, RTV, FIRE
170.175–170.225	GOVT
170.245–170.305	Wireless Mikes
170.350–170.400	GOVT, MIL
170.425–170.450	BIFC
170.475	PUB
170.4875–173.175	GOVT, PUB, Wireless Mikes
173.225–173.5375	MOV, NEWS, UTIL, MIL
173.5625–173.5875	MIL Medical/Crash Crews
173.60–173.9875	GOVT

ULTRA HIGH FREQUENCY (UHF) — (300 MHz–3 GHz)

Military Aircraft Band (381.8-383.9 MHz)

381.800-383.900	Coast Guard
-----------------	-------------

U. S. Government Band (406–420 MHz)

406.125–419.975	GOVT, USXX
-----------------	------------

70-Centimeter Amateur Band (420–450 MHz)

420.000–450.000	HAM
-----------------	-----

Low Band (450–470 MHz)

450.050–450.925	RTV
451.025–452.025	IND, OIL, TELM, UTIL
452.0375–453.00	IND, TAXI, TRAN TOW, NEWS
453.0125–454.000	PUB, OIL
454.025–454.975	TELB
455.050–455.925	RTV
457.525–457.600	BUS
458.025–458.175	MED
460.0125–460.6375	FIRE, POL, PUB
460.650–462.175	BUS
462.1875–462.450	BUS, IND
462.4625–462.525	IND, OIL, TELM, UTIL
462.550–462.925	GMR, BUS
462.9375–463.1875	MED
463.200–467.925	BUS

FM-TV Audio Broadcast, UHF Wide Band (470–512 MHz) (Channels 14 through 20 in 6 MHz steps)

475.750	Channel 14
481.750	Channel 15
487.750	Channel 16
493.750	Channel 17
499.750	Channel 18
505.750	Channel 19
511.750	Channel 20

Note: Some cities use the 470–512 MHz band for land/mobile service.

Conventional Systems Band – Locally Assigned

851.0125–855.9875 CSB

Conventional/Trunked Systems Band – Locally Assigned

856.0125–860.9875 CTSB

Trunked Systems Band – Locally Assigned

861.0125–865.9875 TSB

Public Safety Band – Locally Assigned

866.0125–868.9875 PSB

33-Centimeter Amateur Band (902–928 MHz)

902.0000–928.0000 HAM

Private Trunked

935.0125–939.9875 PTR

General Trunked

940.0125–940.9875 GTR

FREQUENCY CONVERSION

The tuning location of a station can be expressed in frequency (kHz or MHz) or in wavelength (meters). The following information can help you make the necessary conversions.

1 MHz (million) = 1,000 kHz (thousand)

- To convert MHz to kHz, multiply the number of megahertz by 1,000:
$$30.62 \text{ (MHz)} \times 1000 = 30,620 \text{ kHz}$$
- To convert from kHz to MHz, divide the number of kilohertz by 1,000:
$$127,800 \text{ (kHz)} \div 1000 = 127.8 \text{ MHz}$$
- To convert MHz to meters, divide 300 by the number of megahertz:
$$300 \div 50 \text{ MHz} = 6 \text{ meters}$$

TROUBLESHOOTING

If your scanner is not working as it should, these suggestions might help you eliminate the problem. If the scanner still does not operate properly, take it to your local RadioShack store for assistance.

PROBLEM	POSSIBLE CAUSE	REMEDY
Scanner is on but will not scan.	SQUELCH is not correctly adjusted.	Adjust SQUELCH clockwise.
	Only one channel or no channels are stored.	Store frequencies into more than one channel.
Scanner is totally inoperative.	No power.	Make sure the scanner is plugged into a working AC or DC outlet.
	The AC or DC adapter is not connected.	Be sure the adapter's barrel plug is fully inserted into the DC 13.8V jack.
	The scanner must be reset or initialized.	Reset or initialize the scanner (see "Resetting/Initializing the Scanner" on Page 52).
Poor or no reception	An antenna is not connected or connected incorrectly.	Make sure an antenna is connected to the scanner.
Error appears.	Programming error.	Reprogram the frequency correctly, including the decimal point.
In the scan mode, the scanner locks on frequencies that have an unclear transmission.	Programmed frequencies are the same as "birdie" frequencies.	Avoid programming frequencies listed under "Birdie Frequencies" on Page 44 or only listen to them manually.
Scanner will not track a trunked system.	The transmission might not use a system that can be tracked by your scanner.	Scan another transmission.

RESETTING/ INITIALIZING THE SCANNER

You might need to reset or initialize the scanner if:

- the scanner's display locks up.
- the scanner does not work properly after you connect power.
- the scanner is dropped or subjected to a physical or electrical shock.

Important: If you have problems, first try to reset the scanner. If that does not work, you can initialize the scanner; however, this clears all information stored in your scanner's memory.

Resetting the Scanner

1. Turn off the scanner, then turn it on again. **Welcome To Multi-System Trunking** appears.
2. Insert a pointed object, such as a straightened paper clip, into the reset hole on the back of the scanner. Then gently press and release the reset button inside the opening.

Note: Pressing the reset button does not clear the scanner's memory.

Initializing the Scanner

Important: This procedure clears all the information you have programmed into the scanner. Use this procedure only when you are sure your scanner is not working properly.

To initialize the scanner, turn off the scanner then turn it on again. Then, while **Welcome To Multi-System Trunking** appears, press **0** then **1**. **Please Wait.** appears for about 25 seconds, then **Welcome To Multi-System Trunking** appears again.

Important: Do not turn off the scanner until **Welcome To Multi-System Trunking** appears again.

CARE AND MAINTENANCE

Your RadioShack 500-Channel Mobile Trunk-Tracking Scanner is an example of superior design and craftsmanship. The following suggestions will help you care for your scanner so you can enjoy it for years.



Keep the scanner dry. If it gets wet, wipe it dry immediately. Liquids might contain minerals that can corrode the electronic circuits.



Use and store the scanner only in normal temperature environments. Temperature extremes can shorten the life of electronic devices and distort or melt plastic parts.



Keep the scanner away from dust and dirt, which can cause premature wear of parts.



Handle the scanner gently and carefully. Dropping it can damage circuit boards and cases and can cause the scanner to work improperly.



Wipe the scanner with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the scanner.

Modifying or tampering with the scanner's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your scanner is not performing as it should, take it to your local RadioShack store for assistance.

SPECIFICATIONS

Frequency Coverage (MHz):

10 Meter Amateur Radio	29.0000–30.0000 (in 5 kHz steps)
VHF Lo	30.0000–50.0000 (in 5 kHz steps)
6 Meter Amateur Radio	50.0000–54.0000 (in 5 kHz steps)
Aircraft	108.0000–136.9875 (in 12.5 kHz steps)
Government	137.0000–144.0000 (in 5 kHz steps)
2 Meter Amateur Radio	144.0000–148.0000 (in 5 kHz steps)
VHF Hi	148.0000–174.0000 (in 5 kHz steps)
70-cm Amateur Radio/Government	380.0000–450.0000 (in 12.5 kHz steps)
UHF Standard	450.0000–470.0000 (in 12.5 kHz steps)
UHF “T”	470.0000–512.0000 (in 12.5 kHz steps)
Public Service	806.0000–823.9875 (in 12.5 kHz steps)
Public Service/Trunking Repeater	849.0000–868.9875 (in 12.5 kHz steps)
Public Service	894.0000–960.0000 (in 12.5 kHz steps)

Channels of Operation Any 500 channels in any band combinations
(50 channels × 10 banks) and 1000 trunking ID memories

Sensitivity (20 dB S/N):

FM:

29–54 MHz	0.3 μ V
108–136.9875 MHz	0.3 μ V
137–174 MHz	0.5 μ V
380–512 MHz	0.5 μ V
806–960 MHz	0.7 μ V

AM:

29–54 MHz	1 μ V
108–136.9875 MHz	1 μ V
137–174 MHz	1.5 μ V
380–512 MHz	2 μ V
806–960 MHz	2 μ V

Spurious Rejection (@154 MHz FM) 40 dB

Selectivity:

±10 kHz	–6 dB
±18 kHz	–50 dB

Search Speed 50 Steps/Sec (Max)

Scan Speed 25 Channels/Sec. (Nominal)

Priority Sampling 2 Seconds

Delay Time	2 Seconds
IF Rejection:	
257.5 MHz at 154 MHz	60 dB
21.4 MHz at 154 MHz	100 dB
IF Frequencies:	
1st IF	257.5 MHz
2nd IF	21.4 MHz
3rd IF	455 kHz
Squelch Sensitivity:	
Threshold (FM and AM)	0.5 μ V
Tight (FM)	25 dB
Tight (AM)	20 dB
Antenna Impedance	50 Ohms
Audio Output Power (10% THD)	1.5 W
Built-in Speaker	3 ¹ / ₁₆ Inches (77 mm) (8-Ohm, Dynamic Type)
Power Requirements:	13.8V DC
Current Drain	500 mA
Operating Temperature	-4° to 140°F (-20° to 60°C)
Dimensions (HWD)	2 × 6 ¹¹ / ₁₆ × 5 ¹ / ₂ in (50 × 170 × 140 mm)
Weight	32.5 oz (920 g)

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

Limited One-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for one (1) year from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99

**RadioShack Corporation
Fort Worth, Texas 76102**