




## **PROGRAM BC72 AND BC92**

### **Turn on the Scanner and Set Squelch**

1. Turn Squelch fully counterclockwise.
2. Press and hold  for 2 seconds to turn the scanner on, then turn Volume clockwise until you hear a hissing sound.
3. If the scanner is scanning, press Hold to stop scanning, then turn Squelch clockwise until the hissing stops.

### **Store Known Frequencies in Channels**

1. Press Hold. Then enter the channel number where you want to store a frequency. Then press Func. and Pgm. The channel number appears.
2. Use the number keys and enter the frequency (including decimal point) you want to store.
3. Press E to store the frequency in the channel.
4. To program the next channel in sequence, press E and repeat Steps 2 and 3.